



Activate

Grill Cleaner

Description

Grill Cleaner removes all types of soiling such as fat, grease and oil residue from hot plates and grills.

Directions for Use

Use Neat from bottle supplied.

Use on warm to medium heat grill or hot plate.

Squirt onto surfaces NEAT (undiluted). Scrub all areas using a griddle pad system until surface is cleaned. Add water while agitating with pad system to keep surface wet.


If heavily soiled repeat process.

If required neutralise with vinegar. Rinse thoroughly with water.

Do NOT spray solution through an atomiser as solution is irritant.

USE ONLY AS DIRECTED

Pack: 1 Litre Squeeze Bottle (6 per carton)



Re-order ACTIVATE
Products through



PFD Order CODE: 269348

For more information about Activate Cleaning Products,
please visit www.activatecleaning.com